

FWD

BE SURE ϕ IS PARALLEL WITH
KEEL OF BOAT BEFORE INSTALLING.

18.31
 ϕ 7.210
BC

ϕ

RECOMMEND DRILLING
HOLE BEFORE
CUTTING LARGE HOLE

0.95
R.375

15.88
 ϕ 6.250
CUT ALONG
THIS LINE

RITCHIE[®]

**MOUNTING TEMPLATE FOR
CATALOG NO. FD-600**

Part No. 6G-0071, Rev 3/12/98