

TOP

BE SURE ϕ IS PARALLEL WITH KEEL OF BOAT BEFORE INSTALLING.

RECOMMEND DRILLING

0.48

ϕ .188 (3/16)
HOLE BEFORE CUTTING
LARGE HOLE

15.08

ϕ 5.936
BC

ϕ

If mounting this Compass to a bulkhead that is NOT perpendicular (90° angle) to the centerline of the boat and/or NOT vertical (90° angle) to the waterline of the boat (boat on level keel), a fairing block MUST be used to make the compass so.

16.19

ϕ 6.375
BC

CUT ALONG

14.61

ϕ 5.750

THIS LINE

BEZEL
OUTLINE

RITCHIE®

MOUNTING TEMPLATE FOR
CATALOG No. BN-202 NAVIGATOR 2000

PART No. NV-0074

Revised 1/28/94