

ASSEMBLY INSTRUCTIONS FOR THE X-TD COMPASS HOLDER MOUNTING KIT

The X-TD compass Holder should be positioned so that the compass installed in it is horizontal and flat when it is mounted. For this purpose a foam pad spacer is provided to compensate for deck shape.

1. Select a desirable location for the compass; close enough for easy reading but out of the way of the paddle.
2. Place the foam pad on the deck, adhesive side up. With a sharp knife, carve the foam until it matches the shape of the deck and the top is flat and level.
3. Slide the 2 clips onto the bungee cord, using the large side holes and tie the ends of the cord to form a loop. Push one clip through each "D" hole, from the bottom, on the X-TD Mounting Plate.
4. Place the Mounting Plate on top of the foam pad, making sure the cord is NOT on top of the pad (but straddles it). DO NOT USE THE PEEL AND STICK YET. Secure the clips to the boat and check that the Mounting Plate sets level. If it does, peel and stick the foam pad to the Plate. Be careful to maintain alignment.
5. If it does not set flat, continue to modify foam or attach clips to a different place on the boat. If the bungee cord is too short, untie the knot and attach the clips to the ends of the cord using the small holes in the bottom of the clips. Using your knife, cut a groove across the peel and stick side of the foam pad for the single bungee cord to slip through. Repeat Step 4.

